



PeiZen (*pay-zen*), Inc.
651 Via Alondra, Suite 702
CAMARILLO, CA 93012

Phone: (805) 484-2454, FAX: (805) 383-5909

E-mail: hlee@flatmonitors.com

Websites: www.flatmonitors.com and www.peizen.com

Assembly Instructions for the Q-1718-RK Rackmount Kit

Tools needed:

1. 11/32 socket wrench
2. No. 2 Philip screw driver
3. Tie wrap tool
4. Wire cutter, angle tipped is recommended.

Procedures:

1. Remove the monitor from its stand by removing four metric screws from its stand. Store the stand in the original box with its associated hardware. In case of warranty service, you will need to put the monitor back into its original configuration.
2. Spread the soft foam pad that comes with the packing material on a tabletop.
3. Lay the monitor face down. Then position the Q-1718-RK on the back of the monitors. Try to pick the best set of four holes to mount the monitor so that it will appear even between the top and bottom edges.



4. Try to use the original metric screws. If they are not long enough, then use the longer metric screws provided. However, be sure to dip the depth of the mounting holes with a toothpick before using the longer screws.
5. Peel off the adhesive paper on the Power Adapter Pads. Attach them to the bottom of the power adapter. This will help to stabilize the power adapter mounted on the back of the Q-1718-RK. Next, secure the power adapter with the two 14" tie wraps provided.



6. The cable clamps provided are used for tying down the power cable, power adapter cable, and the SVGA monitor cable. If they are not the right sizes, please use your own or secure the cables with 4" tie wraps.
7. Trim all tie wraps with a wire cutter.
8. Use the black 10-32 screws to secure the rackmount assembly to your rack.



9. If you have any questions or comments, please call Harry Lee, 805-484-2454 or e-mail to hlee@flatmonitors.com.